

CONCENTRATION PROFILE MEASUREMENTS USING MULTIPLY RESONANT NUCLEAR REACTIONS

M.Kregar, J.Müller, P.Rupnik, F.Špiler

J. Stefan Institute, University of Ljubljana, Ljubljana

The concentration profile of an element, admixed with the uniform sample in surface layers can be conveniently measured, if the yield curve of multiply resonant nuclear reactions, as  $(p, \gamma)$  or  $(p, \alpha \gamma)$  is properly analysed. The integral yield of nuclear reaction having multiply resonant cross section  $\sigma = \sum_i \sigma_i (l_i^2/4) / ((E' - E_i) + l_i^2/4)$  can be conveniently written as

$$Y(E) = \sum_i \frac{n_F(x_i) \rho_i l_i}{2(dE/dx)_i} g_i$$

$E$  being proton energy at the surface,  $n_F$  the number density of investigated element,  $(dE/dx)_i$  the stopping power of the target at resonant energy  $E_i$  and

$$g_i(E, E_i) = \text{arctg} [2(E - E_i) / l_i] - \text{arctg} [2(E - E_i - \eta) / l_i],$$

where  $\eta$  is the energy depth of the target.

Comparing the yield  $Y(E)$  of investigated sample with the yield  $Y_0(E)$  of homogenous calibration target, relative density of the measured element in the target  $\rho_F$  to the relative density of the same element in standard  $\rho_{oF}$  is

$$\frac{\rho_F}{\rho_{oF}} = \frac{(dE/\rho dx) \cdot Y(E)}{(dE/\rho dx)_o \cdot Y(E)_o} \cdot \frac{1}{f} \quad (1)$$

$$f = 1 + \sum (k_i - 1) r_i g_i / \sum r_i g_i \quad ; \quad k_i = n_F(x_i) / n_F(x_1) \quad \text{and}$$

$$r_i = \sigma_i l_i (dE/\rho dx)_{o1} / \sigma_1 l_1 (dE/\rho dx)_{o1}$$

Iterative procedure is used to evaluate the relative density  $\rho_F$ , using eq. (1).

This method has been successfully used to measure the fluorine density distribution in 12  $\mu\text{m}$  thick surface layers of tooth enamel with the depth resolution 0,1  $\mu\text{m}$  at the surface.